

Наименование	Бренд	Старое наименование
12.80100	GEYER	12.80100_KX-38-32.768kHz-12.5pF
12.80110	GEYER	12.80110_KX-26-77.50kHz
12.88126	GEYER	12.88126_KX-КТ-19.66080MHz
12.89593	GEYER	12.89593_KX-КТ-27.0MHz
12.94108	GEYER	12.94108_KXO-V97T-50.0MHz
12.87708	GEYER	KX-12B 10.0 MHz
12.87703	GEYER	KX-12B 12.0 MHz 30/50/60 16pF
12.87745	GEYER	KX-12B 12.80 MHz 16 pF 30/50/40
12.87705	GEYER	KX-12B 14.318180 MHz 30/50/40 16pF
12.87733	GEYER	KX-12B 14.74560 MHz 30/50/40 16pF
12.87701	GEYER	KX-12B 16.0 MHz 30/50/40 16pF
12.87732	GEYER	KX-12B 18.4320 MHz 30/50/50 16pF
12.87700	GEYER	KX-12B 20.0 MHz 30/50/40 16pF
12.87710	GEYER	KX-12B 24.0 MHz 30/50/40 16pF
12.87724	GEYER	KX-12B 24.5760 MHz 30/50/40 16pF
12.87706	GEYER	KX-12B 25.0 MHz 30/50/40 16pF
12.87725	GEYER	KX-12B 27.0 MHz 30/50/40 16pF
12.87759	GEYER	KX-12B 32.7680 MHz
12.87738	GEYER	KX-12BT 10.0 MHz 30/100/80 16pF
12.87737	GEYER	KX-12BT 12.0 MHz 30/100/60 16pF
12.87740	GEYER	KX-12BT 18.4320 MHz
12.87729	GEYER	KX-12BT 25.0 MHz 30/100/40 16pF
12.87742	GEYER	KX-12BT 40.0 MHz 15/15/40 20pF
12.87905	GEYER	KX-13 10.0 MHz
12.87914	GEYER	KX-13 11.05920 MHz
12.87902	GEYER	KX-13 12.0 MHz
12.87901	GEYER	KX-13 13.0 MHz
12.87911	GEYER	KX-13 13.560 MHz 50/50/50 20pF
12.87906	GEYER	KX-13 14.318180 MHz
12.87907	GEYER	KX-13 14.74560 MHz
12.87903	GEYER	KX-13 16.0 MHz
12.87978	GEYER	KX-13 16.3840 MHz
12.87960	GEYER	KX-13 18.4320 MHz
12.87904	GEYER	KX-13 20.0 MHz
12.87953	GEYER	KX-13 22.11840 MHz
12.87910	GEYER	KX-13 24.0 MHz
12.87913	GEYER	KX-13 25.0 MHz
12.85016	GEYER	KX-13 26.0 MHz
12.85026	GEYER	KX-13 26.0 MHz 20/50/40
12.87918	GEYER	KX-13 40.0 MHz 30/50/30 16pF
12.87919	GEYER	KX-13 50.0 MHz
12.87971	GEYER	KX-13 6.0 MHz
12.87972	GEYER	KX-13 6.1440 MHz
12.87992	GEYER	KX-13 7.15050 MHz
12.87973	GEYER	KX-13 7.37280 MHz
12.87920	GEYER	KX-13 8.0 MHz
12.87988	GEYER	KX-13 8.1920 MHz
12.87981	GEYER	KX-13 9.2160 MHz
12.85028	GEYER	KX-13C 30.0 MHz 50/50/40 16pF
12.87957	GEYER	KX-13E 8.0 MHz
12.87986	GEYER	KX-13T 10.0 MHz
12.87985	GEYER	KX-13T 11.05920 MHz
12.87944	GEYER	KX-13T 12.0 MHz
12.87969	GEYER	KX-13T 13.560 MHz
12.87950	GEYER	KX-13T 14.318180 MHz

12.87939	GEYER	KX-13T 16.0 MHz
12.85011	GEYER	KX-13T 18.4320 MHz
12.87970	GEYER	KX-13T 20.0 MHz
12.87975	GEYER	KX-13T 22.11840 MHz
12.87974	GEYER	KX-13T 25.0 MHz
12.87990	GEYER	KX-13T 6.0 MHz
12.87980	GEYER	KX-13T 6.1440 MHz 50/100/80 16pF
12.87987	GEYER	KX-13T 7.37280 MHz
12.87961	GEYER	KX-13T 8.0 MHz
12.87201	GEYER	KX-14T 4.0 MHz 30/100 16pF
12.87509	GEYER	KX-20 10.0 MHz
12.87510	GEYER	KX-20 11.05920 MHz 50/50/50 16pF
12.87515	GEYER	KX-20 16.0 MHz
12.87526	GEYER	KX-20 16.3840 MHz 50/50/50 16pF
12.87516	GEYER	KX-20 18.4320 MHz
12.87517	GEYER	KX-20 19.66080 MHz
12.87518	GEYER	KX-20 20.0 MHz 50/50/50 16pF
12.87535	GEYER	KX-20 22.11840 MHz 50/50/50 16pF
12.87519	GEYER	KX-20 24.0 MHz 50/50/50 16pF
12.87538	GEYER	KX-20 25.0 MHz 50/50/50 16pF
12.87500	GEYER	KX-20 3.5795450 MHz
12.87501	GEYER	KX-20 3.68640 MHz
12.87502	GEYER	KX-20 4.0 MHz
12.87504	GEYER	KX-20 4.91520 MHz
12.87536	GEYER	KX-20 5.0 MHz
12.87522	GEYER	KX-20 6.0 MHz
12.87523	GEYER	KX-20 6.1440 MHz
12.87524	GEYER	KX-20 8.0 MHz
12.87532	GEYER	KX-20 8.1920 MHz
12.87506	GEYER	KX-20 9.2160 MHz
12.87508	GEYER	KX-20 9.83040 MHz
12.87558	GEYER	KX-20T 10.0 MHz
12.87579	GEYER	KX-20T 12.2880 MHz
12.87548	GEYER	KX-20T 14.318180 MHz
12.87547	GEYER	KX-20T 16.0 MHz
12.87575	GEYER	KX-20T 3.5795450 MHz
12.87546	GEYER	KX-20T 3.68640 MHz
12.87553	GEYER	KX-20T 4.0 MHz
12.87572	GEYER	KX-20T 5.0 MHz
12.87551	GEYER	KX-20T 8.0 MHz
12.80116	GEYER	KX-26 32.768 kHz
12.80111	GEYER	KX-26 32.768 kHz 30/0.042 12.5
12.80113	GEYER	KX-26 32.7680 kHz 20ppm 40k 6pF
12.80118	GEYER	KX-26GWT 32.768 kHz
12.80115	GEYER	KX-26T 32.768 kHz
12.80121	GEYER	KX-26T 77.50 kHz
12.87170	GEYER	KX-327FT 32.768 KHz
12.87130	GEYER	KX-327L 32.768 kHz
12.87134	GEYER	KX-327L 32.7680 kHz 10ppm 50k 7pF
12.87132	GEYER	KX-327L 32.7680 kHz 7pF
12.87131	GEYER	KX-327LT 32.7680 kHz
12.87138	GEYER	KX-327LT 32.7680 kHz 5ppm 12.5pF
12.87135	GEYER	KX-327LT 32.7680 kHz 7pF
12.87147	GEYER	KX-327NHT 32.768 kHz 10ppm 7pF
12.87148	GEYER	KX-327NHT 32.768 kHz 20/50k 7pF
12.87153	GEYER	KX-327NHT 32.768 kHz 7pF

12.87150	GEYER	KX-327NHT 32.7680 kHz
12.87154	GEYER	KX-327NHT 32.7680 kHz 20ppm 12.5pF
12.87160	GEYER	KX-327RT 32.768 KHZ
12.87116	GEYER	KX-327S 32.768 kHz 10 ppm
12.87112	GEYER	KX-327S 32.768 kHz 20 ppm
12.87110	GEYER	KX-327S 32.768 kHz 30 ppm
12.87107	GEYER	KX-327S 32.7680 kHz 20ppm 30k 12.5pF
12.87113	GEYER	KX-327S 32.7680 kHz 5ppm 50k 12.5pF
12.87115	GEYER	KX-327ST 32.768 kHz 10 ppm
12.87114	GEYER	KX-327ST 32.768 kHz 20 ppm
12.87111	GEYER	KX-327ST 32.768 kHz 30 ppm
12.87119	GEYER	KX-327ST 32.7680 kHz 20ppm 50k 6pF
12.87126	GEYER	KX-327XS 32.768 kHz
12.87120	GEYER	KX-327XS 32.768 kHz 30/0.034 12.5
12.87123	GEYER	KX-327XS 32.768 kHz 6pF
12.87121	GEYER	KX-327XST 32.768 kHz
12.80140	GEYER	KX-38 32.768 kHz 12.5pF 10 ppm
12.80106	GEYER	KX-38 32.768 kHz 12.5pF 20ppm
12.80104	GEYER	KX-38 32.768 kHz 6pF
12.80101	GEYER	KX-38T 32.768 kHz 12.5pF [80101] LF
12.80108	GEYER	KX-38T 32.768 kHz 12.5pF [80108] LF
12.80123	GEYER	KX-38T 32.768 kHz 12.5pF 10 ppm
12.80141	GEYER	KX-38T 32.768 kHz 5 ppm
12.80107	GEYER	KX-38T 32.768 kHz 6pF
12.80316	GEYER	KX-39 10.0 MHz
12.80318	GEYER	KX-39 11.0592 MHz
12.80320	GEYER	KX-39 16.0 MHz
12.80322	GEYER	KX-39 20.0 MHz
12.80300	GEYER	KX-39 3.68640 MHz
12.80305	GEYER	KX-39 4.0 MHz
12.80344	GEYER	KX-39F 4.096 MHz
12.80323	GEYER	KX-39T 10.0 MHz
12.80338	GEYER	KX-39T 4.0 MHz
12.80345	GEYER	KX-39T 8.0 MHz
12.84110	GEYER	KX-3H 10.0 MHz
12.84148	GEYER	KX-3H 11.0 MHz
12.84111	GEYER	KX-3H 11.0592 MHz
12.84112	GEYER	KX-3H 12.0 MHz
12.84113	GEYER	KX-3H 12.2880 MHz
12.84307	GEYER	KX-3H 13.2256250 MHz
12.84305	GEYER	KX-3H 13.560 MHz
12.84114	GEYER	KX-3H 14.0 MHz
12.84115	GEYER	KX-3H 14.318180 MHz
12.84116	GEYER	KX-3H 14.74560 MHz
12.84144	GEYER	KX-3H 15.0 MHz
12.84119	GEYER	KX-3H 16.0 MHz
12.84136	GEYER	KX-3H 16.3840 MHz
12.84157	GEYER	KX-3H 17.7344750 MHz
12.84134	GEYER	KX-3H 18.0 MHz
12.84121	GEYER	KX-3H 18.4320 MHz
12.84120	GEYER	KX-3H 19.66080 MHz
12.84122	GEYER	KX-3H 20.0 MHz
12.84131	GEYER	KX-3H 22.11840 MHz
12.84125	GEYER	KX-3H 24.0 MHz
12.84124	GEYER	KX-3H 24.5760 MHz
12.84126	GEYER	KX-3H 25.0 MHz

12.84140	GEYER	KX-3H 27.0 MHz
12.84141	GEYER	KX-3H 28.0 MHz
12.84155	GEYER	KX-3H 28.375 MHz 16 pF 50/50/100 LF
12.84487	GEYER	KX-3H 28.636360 MHz
12.84133	GEYER	KX-3H 3.27680 MHz
12.84100	GEYER	KX-3H 3.5795450 MHz
12.84101	GEYER	KX-3H 3.68640 MHz
12.84160	GEYER	KX-3H 30.0 MHz
12.84142	GEYER	KX-3H 32.0 MHz
12.84102	GEYER	KX-3H 4.0 MHz
12.84117	GEYER	KX-3H 4.0960 MHz
12.84103	GEYER	KX-3H 4.1943040 MHz
12.84128	GEYER	KX-3H 4.4336190 MHz
12.84105	GEYER	KX-3H 4.91520 MHz
12.84138	GEYER	KX-3H 40.0 MHz
12.84139	GEYER	KX-3H 5.0 MHz
12.84409	GEYER	KX-3H 5.90 MHz 20 pF 20/50/120
12.84106	GEYER	KX-3H 6.0 MHz
12.84127	GEYER	KX-3H 6.1440 MHz
12.84444	GEYER	KX-3H 7.159090 MHz
12.84107	GEYER	KX-3H 7.37280 MHz
12.84251	GEYER	KX-3H 7.60 MHz
12.84147	GEYER	KX-3H 7.680 MHz
12.84108	GEYER	KX-3H 8.0 MHz
12.84523	GEYER	KX-3H 8.0 MHz 10/15ppm 12pF
12.84135	GEYER	KX-3H 8.1920 MHz
12.84146	GEYER	KX-3H 9.2160 MHz
12.84109	GEYER	KX-3H 9.83040 MHz
12.84501	GEYER	KX-3HE 12.0 MHz
12.84405	GEYER	KX-3HE 8.0 MHz
12.84200	GEYER	KX-3HT 10.0 MHz
12.84311	GEYER	KX-3HT 11.0 MHz
12.84233	GEYER	KX-3HT 11.05920 MHz
12.84309	GEYER	KX-3HT 12.0 MHz
12.84213	GEYER	KX-3HT 12.0 MHz 30/150/80
12.84302	GEYER	KX-3HT 12.2880 MHz
12.84371	GEYER	KX-3HT 13.0 MHz
12.84422	GEYER	KX-3HT 13.560 MHz
12.84376	GEYER	KX-3HT 14.0 MHz
12.84218	GEYER	KX-3HT 14.318180 MHz
12.84247	GEYER	KX-3HT 14.74560 MHz
12.84417	GEYER	KX-3HT 15.0 MHz
12.84207	GEYER	KX-3HT 16.0 MHz
12.84256	GEYER	KX-3HT 16.3840 MHz
12.84416	GEYER	KX-3HT 16.6675 MHz
12.84418	GEYER	KX-3HT 18.0 MHz
12.84217	GEYER	KX-3HT 18.4320 MHz
12.84257	GEYER	KX-3HT 20.0 MHz
12.84320	GEYER	KX-3HT 22.11840 MHz
12.84265	GEYER	KX-3HT 24.0 MHz
12.84244	GEYER	KX-3HT 24.5760 MHz
12.84290	GEYER	KX-3HT 25.0 MHz
12.84308	GEYER	KX-3HT 27.0 MHz
12.84230	GEYER	KX-3HT 3.27680 MHz
12.84258	GEYER	KX-3HT 3.5795450 MHz
12.84232	GEYER	KX-3HT 3.68640 MHz

12.84253	GEYER	KX-3HT 30.0 MHz
12.84229	GEYER	KX-3HT 4.0 MHz
12.84356	GEYER	KX-3HT 4.0320 MHz
12.84406	GEYER	KX-3HT 4.0960 MHz
12.84184	GEYER	KX-3HT 4.1943040 MHz
12.84236	GEYER	KX-3HT 4.91520 MHz
12.84191	GEYER	KX-3HT 5.0 MHz
12.84246	GEYER	KX-3HT 6.0 MHz
12.84539	GEYER	KX-3HT 6.1440 MHz
12.84325	GEYER	KX-3HT 6.290 MHz
12.84420	GEYER	KX-3HT 7.1680 MHz
12.84235	GEYER	KX-3HT 7.37280 MHz
12.84203	GEYER	KX-3HT 8.0 MHz
12.84424	GEYER	KX-3HT 8.1920 MHz
12.84410	GEYER	KX-3HT 9.2160 MHz
12.86100	GEYER	KX-45 1.0 MHz
12.86124	GEYER	KX-45T 1.0 MHz
12.81172	GEYER	KX-49 1.84320 MHz
12.81302	GEYER	KX-49 10.0 MHz
12.81315	GEYER	KX-49 11.0592 MHz
12.81316	GEYER	KX-49 12.0 MHz
12.81422	GEYER	KX-49 12.288 MHz
12.81326	GEYER	KX-49 14.31818 MHz
12.81328	GEYER	KX-49 14.7456 MHz
12.81334	GEYER	KX-49 16.0 MHz
12.81335	GEYER	KX-49 16.384 MHz
12.81167	GEYER	KX-49 16.66330 MHz
12.81337	GEYER	KX-49 17.734476 MHz
12.81340	GEYER	KX-49 18.432 MHz
12.81344	GEYER	KX-49 19.6608 MHz
12.81176	GEYER	KX-49 2.0 MHz
12.81186	GEYER	KX-49 2.4576 MHz
12.81348	GEYER	KX-49 20.0 MHz
12.81096	GEYER	KX-49 20.0 MHz 10/50/40
12.81354	GEYER	KX-49 22.1184 MHz
12.81358	GEYER	KX-49 24.0 MHz
12.81360	GEYER	KX-49 24.576 MHz
12.81212	GEYER	KX-49 3.579545 MHz
12.81216	GEYER	KX-49 3.6864 MHz
12.81372	GEYER	KX-49 30.0 MHz
12.81387	GEYER	KX-49 37.5 MHz
12.81224	GEYER	KX-49 4.0 MHz
12.81230	GEYER	KX-49 4.194304 MHz
12.81255	GEYER	KX-49 4.608 MHz
12.81246	GEYER	KX-49 4.9152 MHz
12.81250	GEYER	KX-49 5.0 MHz
12.81272	GEYER	KX-49 6.0 MHz
12.81286	GEYER	KX-49 7.15909 MHz 30pF 30/50/60
12.81288	GEYER	KX-49 7.3728 MHz
12.81290	GEYER	KX-49 8.0 MHz
12.81291	GEYER	KX-49 8.192 MHz
12.81300	GEYER	KX-49 9.8304 MHz
12.81386	GEYER	KX-49E 8.0 MHz 30pF 50/150/60
12.81175	GEYER	KX-49T 1.8432 MHz
12.81119	GEYER	KX-49T 10.0 MHz
12.81042	GEYER	KX-49T 11.0592 MHz

12.81040	GEYER	KX-49T 12.0 MHz
12.81110	GEYER	KX-49T 16.0 MHz
12.81486	GEYER	KX-49T 17.17760 MHz 20pF 20/100/40
12.81336	GEYER	KX-49T 18.432 MHz
12.81018	GEYER	KX-49T 2.0 MHz
12.81318	GEYER	KX-49T 22.1184 MHz
12.81118	GEYER	KX-49T 3.0 MHz
12.81056	GEYER	KX-49T 3.579545 MHz
12.81217	GEYER	KX-49T 3.6864 MHz
12.81222	GEYER	KX-49T 4.0 MHz
12.81281	GEYER	KX-49T 4.096 MHz
12.81228	GEYER	KX-49T 7.3728 MHz
12.81439	GEYER	KX-49T 8.0 MHz
12.81158	GEYER	KX-49T 9.83040 MHz
12.84817	GEYER	KX-4T 50.0 MHz 10/15 8pF
12.84811	GEYER	KX-4T 50.0 MHz 15/15/80 8pF
12.85507	GEYER	KX-5 19.20 MHz
12.85509	GEYER	KX-5 20.0 MHz
12.85510	GEYER	KX-5 24.0 MHz
12.85511	GEYER	KX-5 24.5760 MHz
12.85512	GEYER	KX-5 25.0 MHz
12.85563	GEYER	KX-5 25.0 MHz 30/50/100 10pF
12.85515	GEYER	KX-5 27.0 MHz
12.85514	GEYER	KX-5 27.120 MHz
12.85504	GEYER	KX-5T 24.0 MHz
12.85595	GEYER	KX-5T 32.0 MHz 10/15ppm 12pF
12.85582	GEYER	KX-5T 32.0 MHz 10/20ppm 10pF
12.86508	GEYER	KX-6 16.0 MHz
12.86514	GEYER	KX-6 19.20 MHz
12.86512	GEYER	KX-6 20.0 MHz
12.86516	GEYER	KX-6 22.11840 MHz
12.86517	GEYER	KX-6 24.0 MHz
12.86518	GEYER	KX-6 24.5760 MHz
12.86505	GEYER	KX-6 26.0 MHz
12.86500	GEYER	KX-6 32.0 MHz
12.86509	GEYER	KX-6 48.0 MHz
12.86504	GEYER	KX-6T 16.0 MHz
12.86560	GEYER	KX-6T 16.0 MHz 15/25/80 8pF
12.86523	GEYER	KX-6T 22.11840 MHz
12.86561	GEYER	KX-6T 40.0 MHz 10/20ppm 10pF
12.88662	GEYER	KX-7 12.0 MHz 30/50/100 12 pF
12.88627	GEYER	KX-7 12.0 MHz 30/50/100 16 pF
12.88680	GEYER	KX-7 12.2880 MHz
12.88654	GEYER	KX-7 13.0 MHz 30/50/70 18pF
12.88663	GEYER	KX-7 13.560 MHz
12.88664	GEYER	KX-7 14.318180 MHz
12.88657	GEYER	KX-7 14.74560 MHz
12.88602	GEYER	KX-7 16.0 MHz
12.88636	GEYER	KX-7 16.0 MHz 30/50/100 16 pF
12.88453	GEYER	KX-7 16.0 MHz 50/30/80 7pF
12.88552	GEYER	KX-7 16.384 MHz 30/50/100 8pF
12.88606	GEYER	KX-7 18.4320 MHz
12.88610	GEYER	KX-7 20.0 MHz
12.88659	GEYER	KX-7 22.11840 MHz
12.88665	GEYER	KX-7 24.0 MHz
12.88666	GEYER	KX-7 24.5760 MHz

12.88667	GEYER	KX-7 25.0 MHz
12.88767	GEYER	KX-7 26.0 MHz 10/10/50 10pF
12.88646	GEYER	KX-7 26.0 MHz 30/50/100 16pF
12.88623	GEYER	KX-7 27.0 MHz 30/50/50 16 pF
12.88740	GEYER	KX-7 27.12 MHz 30/50/50 12pF
12.88570	GEYER	KX-7 27.120 MHz 10/10/60 10pF
12.88760	GEYER	KX-7 30.0 MHz 20/20/50 10pF
12.88638	GEYER	KX-7 32.0 MHz
12.88580	GEYER	KX-7 32.0 MHz 10/30/40 12pF
12.88734	GEYER	KX-7 40.0 MHz 10/10 15pF
12.88578	GEYER	KX-7 8.0 MHz 10/80/600 8pF
12.60048	GEYER	KX-7F 8.0 MHz 50/150/500 12pF
12.88771	GEYER	KX-7T 10.0 MHz 30/50 16pF
12.88673	GEYER	KX-7T 12.0 MHz
12.88649	GEYER	KX-7T 12.0 MHz 30/100/100 16 pF
12.88692	GEYER	KX-7T 12.0 MHz 30/50 12pF
12.88689	GEYER	KX-7T 13.56 MHz 30/30/100 16 pF
12.88691	GEYER	KX-7T 14.31818 MHz 30/50/100 16pF
12.88639	GEYER	KX-7T 14.318180 MHz
12.88485	GEYER	KX-7T 14.74560 MHz
12.88785	GEYER	KX-7T 16.0 MHz 10/15 9pF
12.88455	GEYER	KX-7T 16.0 MHz 10/20 10pF
12.88684	GEYER	KX-7T 16.0 MHz 12 pF
12.88605	GEYER	KX-7T 16.0 MHz 50/100/100 12 pF
12.60056	GEYER	KX-7T 16.384 MHz 10/20/60 12pF
12.88660	GEYER	KX-7T 18.4320 MHz 16 pF
12.88669	GEYER	KX-7T 20.0 MHz
12.88743	GEYER	KX-7T 20.0 MHz 30/30/60 12pF
12.88650	GEYER	KX-7T 24.0 MHz
12.88727	GEYER	KX-7T 24.0 MHz 10/15 8pF
12.88590	GEYER	KX-7T 24.0 MHz 10/20 9pF
12.88697	GEYER	KX-7T 24.0 MHz 30/100/100 12 pF
12.88609	GEYER	KX-7T 24.5760 MHz 10/30/50 10 pF
12.88656	GEYER	KX-7T 24.5760 MHz 16 pF
12.88514	GEYER	KX-7T 24.5760 MHz 30/30/60 12pF
12.88607	GEYER	KX-7T 25.0 MHz
12.88459	GEYER	KX-7T 25.0 MHz 10/15 12pF
12.60127	GEYER	KX-7T 25.0 MHz 10/15ppm 18pF
12.88596	GEYER	KX-7T 26.0 MHz 10/10 10pF
12.88681	GEYER	KX-7T 26.0 MHz 10/20/100
12.88651	GEYER	KX-7T 27.0 MHz
12.88693	GEYER	KX-7T 27.0 MHz 10/20/100
12.88655	GEYER	KX-7T 30.0 MHz
12.88770	GEYER	KX-7T 30.0 MHz 10/10/70 12pF
12.88652	GEYER	KX-7T 32.0 MHz
12.88549	GEYER	KX-7T 32.0 MHz 10/10 10pF
12.88456	GEYER	KX-7T 32.0 MHz 10/20ppm 16pF
12.60102	GEYER	KX-7T 38.40 MHz 10/20ppm 9pF
12.60063	GEYER	KX-7T 8.0 MHz 30/100 12pF
12.88810	GEYER	KX-8 12.0 MHz
12.88835	GEYER	KX-8 13.0 MHz 30/50/100
12.88809	GEYER	KX-8 16.0 MHz
12.88823	GEYER	KX-8 22.11840 MHz
12.88813	GEYER	KX-8 24.0 MHz
12.88814	GEYER	KX-8 25.0 MHz
12.88834	GEYER	KX-8T 12.2880 MHz

12.88824	GEYER	KX-8T 13.0 MHz
12.88815	GEYER	KX-8T 16.0 MHz
12.88837	GEYER	KX-8T 22.11840 MHz
12.88818	GEYER	KX-8T 25.0 MHz
12.89006	GEYER	KX-9A 10.0 MHz
12.89000	GEYER	KX-9A 11.05920 MHz
12.89014	GEYER	KX-9A 12.0 MHz
12.89009	GEYER	KX-9A 14.74560 MHz
12.89002	GEYER	KX-9A 16.0 MHz
12.89023	GEYER	KX-9A 16.3840 MHz
12.89010	GEYER	KX-9A 18.4320 MHz
12.89011	GEYER	KX-9A 20.0 MHz
12.89012	GEYER	KX-9A 24.0 MHz
12.89013	GEYER	KX-9A 25.0 MHz
12.89042	GEYER	KX-9A 48.0 MHz
12.89007	GEYER	KX-9A 8.0 MHz
12.89169	GEYER	KX-9A 8.1920 MHz 30/50/150 12pF
12.89112	GEYER	KX-9AE 8.0 MHz
12.89038	GEYER	KX-9AT 10.0 MHz
12.89181	GEYER	KX-9AT 10.0 MHz 10/20/100 10pF
12.89045	GEYER	KX-9AT 12.0 MHz
12.89149	GEYER	KX-9AT 12.0 MHz 30/30/60 18pF
12.89037	GEYER	KX-9AT 13.560 MHz
12.89033	GEYER	KX-9AT 14.74560 MHz
12.89005	GEYER	KX-9AT 16.0 MHz
12.89054	GEYER	KX-9AT 18.4320 MHz
12.89031	GEYER	KX-9AT 24.0 MHz
12.89077	GEYER	KX-9AT 24.5760 MHz
12.89004	GEYER	KX-9AT 25.0 MHz
12.89067	GEYER	KX-9AT 26.0 MHz 10/20/40 16 pF
12.89048	GEYER	KX-9AT 8.0 MHz
12.89076	GEYER	KX-9AT 8.1920 MHz
12.89424	GEYER	KX-9BT 10.0 MHz
12.89439	GEYER	KX-9BT 14.74560 MHz
12.89440	GEYER	KX-9BT 24.5760 MHz
12.89422	GEYER	KX-9BT 25.0 MHz
12.87268	GEYER	KX-C 8.0 MHz
12.88200	GEYER	KX-CPB 3.68640 MHz
12.88204	GEYER	KX-CPB 8.0 MHz
12.88250	GEYER	KX-CPBT 18.432 MHz
12.89500	GEYER	KX-INS INSULATOR FOR KX-3H [KX-49]
12.87813	GEYER	KX-K 10.0 MHz
12.87899	GEYER	KX-K 11.0 MHz
12.87802	GEYER	KX-K 11.05920 MHz
12.87806	GEYER	KX-K 12.0 MHz
12.89667	GEYER	KX-K 12.0 MHz 30/50/50 30pF
12.87819	GEYER	KX-K 12.2880 MHz
12.87839	GEYER	KX-K 13.560 MHz
12.87824	GEYER	KX-K 14.318180 MHz
12.87810	GEYER	KX-K 14.74560 MHz
12.87814	GEYER	KX-K 15.0 MHz
12.87800	GEYER	KX-K 16.0 MHz
12.87832	GEYER	KX-K 18.4320 MHz
12.87820	GEYER	KX-K 19.66080 MHz
12.87807	GEYER	KX-K 20.0 MHz
12.89674	GEYER	KX-K 20.0 MHz 30/100/50 20pF

12.87833	GEYER	KX-K 22.11840 MHz
12.87826	GEYER	KX-K 24.0 MHz
12.87801	GEYER	KX-K 24.5760 MHz
12.87849	GEYER	KX-K 25.0 MHz
12.87809	GEYER	KX-K 27.0 MHz
12.87803	GEYER	KX-K 3.5795450 MHz
12.87804	GEYER	KX-K 3.68640 MHz
12.88146	GEYER	KX-K 30.0 MHz
12.87805	GEYER	KX-K 32.0 MHz
12.87811	GEYER	KX-K 33.0 MHz
12.87812	GEYER	KX-K 4.0 MHz
12.87838	GEYER	KX-K 4.0960 MHz
12.87821	GEYER	KX-K 4.1943040 MHz
12.87818	GEYER	KX-K 4.91520 MHz
12.87808	GEYER	KX-K 40.0 MHz
12.87840	GEYER	KX-K 48.0 MHz
12.87817	GEYER	KX-K 5.0 MHz
12.87869	GEYER	KX-K 6.0 MHz
12.87844	GEYER	KX-K 6.1440 MHz
12.87830	GEYER	KX-K 7.37280 MHz
12.87823	GEYER	KX-K 8.0 MHz
12.87825	GEYER	KX-K 9.83040 MHz
12.88052	GEYER	KX-KS 12.0 MHz
12.88009	GEYER	KX-KS 16.0 MHz
12.88054	GEYER	KX-KS 3.68640 MHz
12.88012	GEYER	KX-KS 4.0 MHz
12.88022	GEYER	KX-KS 4.91520 MHz
12.88053	GEYER	KX-KS 8.0 MHz
12.88047	GEYER	KX-KST 10.0 MHz
12.88063	GEYER	KX-KST 10.0 MHz 16pF 10/25/50
12.88073	GEYER	KX-KST 12.0 MHz 16pF 10/25/50 LF
12.88070	GEYER	KX-KST 12.0 MHz 20 pF
12.88078	GEYER	KX-KST 14.74560 MHz 10/25/50
12.88031	GEYER	KX-KST 16.0 MHz
12.88083	GEYER	KX-KST 16.3840 MHz 16PF 10/25/50 LF
12.88080	GEYER	KX-KST 16.3840 MHz 20pF 10/25/50 LF
12.88032	GEYER	KX-KST 18.4320 MHz
12.88157	GEYER	KX-KST 18.4320 MHz 16pF 10/25/50 LF
12.88061	GEYER	KX-KST 19.6608 MHz 16pF 10/25/50 LF
12.88158	GEYER	KX-KST 24.5760 MHz 16pF 10/25/50 LF
12.88087	GEYER	KX-KST 25.0 MHz 16pF 10/25/50 LF
12.88046	GEYER	KX-KST 9.83040 MHz 16pF 10/25/50 LF
12.88125	GEYER	KX-KT 10.0 MHz
12.88114	GEYER	KX-KT 11.05920 MHz
12.88152	GEYER	KX-KT 12.0 MHz
12.89793	GEYER	KX-KT 12.2880 MHz
12.89713	GEYER	KX-KT 13.2256 MHz 10/20 18pF
12.89794	GEYER	KX-KT 13.560 MHz
12.88106	GEYER	KX-KT 14.74560 MHz
12.88131	GEYER	KX-KT 16.0 MHz
12.88162	GEYER	KX-KT 18.4320 MHz
12.89799	GEYER	KX-KT 19.66080 MHz
12.88107	GEYER	KX-KT 20.0 MHz
12.89710	GEYER	KX-KT 20.0 MHz 30/30ppm 12pF
12.87877	GEYER	KX-KT 20.50 MHz
12.88118	GEYER	KX-KT 24.0 MHz

12.88153	GEYER	KX-KT 25.0 MHz
12.89805	GEYER	KX-KT 27.0 MHz
12.88151	GEYER	KX-KT 3.5795450 MHz
12.87881	GEYER	KX-KT 3.68640 MHz
12.89650	GEYER	KX-KT 3.68640 MHz 30/50/150 16 pF
12.89569	GEYER	KX-KT 30.0 MHz
12.89579	GEYER	KX-KT 32.0 MHz
12.87867	GEYER	KX-KT 4.0 MHz
12.88170	GEYER	KX-KT 4.0960 MHz
12.87879	GEYER	KX-KT 4.1943040 MHz
12.88168	GEYER	KX-KT 4.91520 MHz
12.88110	GEYER	KX-KT 5.0 MHz
12.88112	GEYER	KX-KT 6.0 MHz
12.87892	GEYER	KX-KT 6.1440 MHz
12.87835	GEYER	KX-KT 6.7643750 MHz
12.88175	GEYER	KX-KT 6.764380 MHz
12.88127	GEYER	KX-KT 7.37280 MHz
12.87885	GEYER	KX-KT 8.0 MHz
12.89726	GEYER	KX-KT 8.0 MHz 30/30/60 10pF
12.89709	GEYER	KX-KT 8.0 MHz 30/50ppm 16pF
12.89747	GEYER	KX-KT 8.1920 MHz 30/50 16pF
12.87427	GEYER	KX-MC 10.0 MHz
12.87403	GEYER	KX-MC 14.74560 MHz
12.87414	GEYER	KX-MC 18.4320 MHz
12.87407	GEYER	KX-MC 20.0 MHz
12.87417	GEYER	KX-MC 24.0 MHz
12.87401	GEYER	KX-MC 3.5795450 MHz
12.87273	GEYER	KX-MC 3.68640 MHz
12.87436	GEYER	KX-MC 32.0 MHz
12.87421	GEYER	KX-MC 4.0 MHz
12.87405	GEYER	KX-MC 4.91520 MHz
12.87428	GEYER	KX-MC 6.0 MHz
12.87406	GEYER	KX-MC 7.37280 MHz
12.87425	GEYER	KX-MC 8.0 MHz
12.87467	GEYER	KX-MCT 11.05920 MHz
12.87463	GEYER	KX-MCT 16.0 MHz
12.87461	GEYER	KX-MCT 8.0 MHz
12.90101	GEYER	KXO-200 1.8432 MHz DIL14
12.90118	GEYER	KXO-200 10.0 MHz DIL14
12.90143	GEYER	KXO-200 100.0 MHz DIL14
12.90120	GEYER	KXO-200 11.0592 MHz DIL14
12.90121	GEYER	KXO-200 12.0 MHz DIL14
12.90223	GEYER	KXO-200 13.0 MHz DIL14
12.90125	GEYER	KXO-200 14.74560 MHz
12.90126	GEYER	KXO-200 16.0 MHz DIL14
12.90129	GEYER	KXO-200 18.432 MHz DIL14
12.90144	GEYER	KXO-200 20.0 MHz DIL14
12.90174	GEYER	KXO-200 22.5792 MHz
12.90133	GEYER	KXO-200 24.0 MHz DIL14
12.90135	GEYER	KXO-200 25.0 MHz DIL14
12.90137	GEYER	KXO-200 32.0 MHz DIL14
12.90145	GEYER	KXO-200 4.0 MHz DIL14
12.90150	GEYER	KXO-200 48.0 MHz DIL14
12.90151	GEYER	KXO-200 50.0 MHz DIL14
12.90114	GEYER	KXO-200 8.0 MHz DIL14
12.90237	GEYER	KXO-205 14.7456 MHz

12.90187	GEYER	KXO-205 50.0 MHz
12.91511	GEYER	KXO-210 10.0 MHz
12.91514	GEYER	KXO-210 12.0 MHz
12.91542	GEYER	KXO-210 14.31818 MHz
12.91543	GEYER	KXO-210 15.0 MHz
12.91517	GEYER	KXO-210 16.0 MHz
12.91520	GEYER	KXO-210 20.0 MHz
12.91580	GEYER	KXO-210 24.576 MHz
12.91525	GEYER	KXO-210 25.0 MHz
12.91595	GEYER	KXO-210 27.0 MHz
12.91528	GEYER	KXO-210 32.0 MHz
12.91583	GEYER	KXO-210 33.0 MHz
12.91617	GEYER	KXO-210 36.0 MHz
12.91504	GEYER	KXO-210 4.0 MHz
12.91531	GEYER	KXO-210 40.0 MHz
12.91540	GEYER	KXO-210 50.0 MHz
12.91534	GEYER	KXO-210 64.0 MHz
12.91563	GEYER	KXO-210 66.0 MHz
12.91507	GEYER	KXO-210 7.3728 MHz
12.91508	GEYER	KXO-210 8.0 MHz
12.91550	GEYER	KXO-210 80.0 MHz
12.91518	GEYER	KXO-215 16.0 MHz
12.91521	GEYER	KXO-215 20.0 MHz
12.91590	GEYER	KXO-215 24.0 MHz
12.91689	GEYER	KXO-215 24.576 MHz
12.91707	GEYER	KXO-215 4.9152 MHz
12.91581	GEYER	KXO-215 40.0 MHz
12.91033	GEYER	KXO-400 100.0 MHz
12.90159	GEYER	KXO-400 40.0 MHz
12.91030	GEYER	KXO-405 66.0 MHz
12.91031	GEYER	KXO-405 80.0 MHz
12.91032	GEYER	KXO-405 100.0 MHz
12.91584	GEYER	KXO-410 16.384 MHz
12.96718	GEYER	KXO-75 74.250 MHz
12.96820	GEYER	KXO-800 80.0 MHz
12.96821	GEYER	KXO-800 16.384 MHz
12.96815	GEYER	KXO-800 34.368 MHz
12.96814	GEYER	KXO-800T 27.0 MHz
12.97468	GEYER	KXO-84 26.0 MHz 2.5ppm 3.3V SINEWAVE
12.97494	GEYER	KXO-84T 16.0 MHz 1.5ppm 3.3V
12.97599	GEYER	KXO-84T 16.3840 MHz 1ppm 3.3V
12.97477	GEYER	KXO-84T 24.0 MHz 2.5ppm 3.3V
12.97004	GEYER	KXO-85 20.0 MHz
12.97503	GEYER	KXO-86T 26.0 MHz 1.5ppm 1.8V
12.96516	GEYER	KXO-900 20.0 MHz
12.96552	GEYER	KXO-900 66.0 MHz
12.96532	GEYER	KXO-900T 10.0 MHz
12.96560	GEYER	KXO-900T 100.0MHZ 2PPM
12.96559	GEYER	KXO-900T 20.0 MHz
12.96547	GEYER	KXO-900T 40.0 MHz
12.96561	GEYER	KXO-900T 80.0 MHz
12.96604	GEYER	KXO-950 27.0 MHz
12.94212	GEYER	KXO-97 12.2880 MHz
12.94214	GEYER	KXO-97 14.7456 MHz
12.94215	GEYER	KXO-97 16.0 MHz
12.94515	GEYER	KXO-97 16.9344 MHz

12.94219	GEYER	KXO-97 20.0 MHz
12.94248	GEYER	KXO-97 22.0 MHz 50ppm 5V TTL/CMOS
12.94220	GEYER	KXO-97 22.11840 MHz 50ppm 5V TTL/CMOS
12.94240	GEYER	KXO-97 25.0 MHz
12.94256	GEYER	KXO-97 25.175 MHz
12.94222	GEYER	KXO-97 30.0 MHz
12.94223	GEYER	KXO-97 32.0 MHz
12.94203	GEYER	KXO-97 4.0 MHz
12.94225	GEYER	KXO-97 40.0 MHz
12.94230	GEYER	KXO-97 66.0 MHz
12.94207	GEYER	KXO-97 8.0 MHz
12.94233	GEYER	KXO-97 80.0 MHz
12.94299	GEYER	KXO-97T 1.8432 MHz
12.94436	GEYER	KXO-97T 10.0 MHz
12.94563	GEYER	KXO-97T 100.0 MHz
12.94380	GEYER	KXO-97T 11.0592 MHz
12.94288	GEYER	KXO-97T 12.0 MHz
12.94289	GEYER	KXO-97T 16.0 MHz
12.94287	GEYER	KXO-97T 20.0 MHz
12.94295	GEYER	KXO-97T 40.0 MHz
12.94286	GEYER	KXO-97T 48.0 MHz
12.94441	GEYER	KXO-97T 5.0 MHz
12.94284	GEYER	KXO-97T 50.0 MHz
12.94326	GEYER	KXO-97T 64.0 MHz
12.94321	GEYER	KXO-97T 7.3728 MHz
12.94291	GEYER	KXO-97T 8.0 MHz
12.94349	GEYER	KXO-97T 80.0 MHz
12.75000	GEYER	KXO-V32T 32.768 kHz 20ppm 3.3V
12.93405	GEYER	KXO-V63 102.4 MHz 3.3V
12.93602	GEYER	KXO-V65T 125.0 MHz 2.5V
12.90302	GEYER	KXO-V94T 8.000 MHz 3.3V
12.95505	GEYER	KXO-V95 16.0 MHz 3.0V
12.95042	GEYER	KXO-V96 11.0592 MHz
12.95007	GEYER	KXO-V96 20.0 MHz 3.3V
12.95008	GEYER	KXO-V96 24.0 MHz 50ppm 3.3V
12.95004	GEYER	KXO-V96 27.0 MHz 50ppm 3.3V
12.95035	GEYER	KXO-V96 50.0 MHz
12.95014	GEYER	KXO-V96 80.0 MHz 50ppm 3.3V HCMOS
12.95104	GEYER	KXO-V96T 32.768 KHZ 1.8V
12.94346	GEYER	KXO-V97 10.0 MHz
12.94355	GEYER	KXO-V97 100.0 MHz
12.94438	GEYER	KXO-V97 12.0 MHz
12.94503	GEYER	KXO-V97 120.0 MHz
12.94341	GEYER	KXO-V97 125.0 MHz
12.94356	GEYER	KXO-V97 14.7456 MHz
12.94272	GEYER	KXO-V97 16.0 MHz
12.94453	GEYER	KXO-V97 18.0 MHz 50ppm 3.3V
12.94384	GEYER	KXO-V97 18.432 MHz
12.94265	GEYER	KXO-V97 20.0 MHz
12.94340	GEYER	KXO-V97 24.0 MHz
12.94345	GEYER	KXO-V97 24.5760 MHz
12.94335	GEYER	KXO-V97 25.0 MHz
12.94336	GEYER	KXO-V97 27.0 MHz
12.94446	GEYER	KXO-V97 29.49120 MHz
12.94377	GEYER	KXO-V97 3.6864 MHz
12.94314	GEYER	KXO-V97 30.0 MHz

12.94343	GEYER	KXO-V97 32.0 MHz
12.94430	GEYER	KXO-V97 32.768 MHz
12.94496	GEYER	KXO-V97 32.7680 kHz 50ppm 3.3V
12.94358	GEYER	KXO-V97 33 MHz
12.94457	GEYER	KXO-V97 36.8640 MHz
12.94274	GEYER	KXO-V97 40.0 MHz
12.94260	GEYER	KXO-V97 48.0 MHz
12.94277	GEYER	KXO-V97 50.0 MHz
12.94525	GEYER	KXO-V97 50.0 MHz 25ppm 3.3V
12.94476	GEYER	KXO-V97 54.0 MHz
12.94370	GEYER	KXO-V97 6.0 MHz
12.94399	GEYER	KXO-V97 6.1440 MHz 50ppm 3.3V
12.94344	GEYER	KXO-V97 66.0 MHz
12.94372	GEYER	KXO-V97 8.0 MHz
12.94280	GEYER	KXO-V97 80.0 MHz
12.94450	GEYER	KXO-V97T 10.0 MHz
12.94350	GEYER	KXO-V97T 100.0 MHz
12.94578	GEYER	KXO-V97T 12MHz 3.3V
12.94398	GEYER	KXO-V97T 14.7456 MHz
12.94328	GEYER	KXO-V97T 20.0 MHz
12.94369	GEYER	KXO-V97T 24.0 MHz
12.94403	GEYER	KXO-V97T 25.0 MHz
12.94437	GEYER	KXO-V97T 30.0 MHz
12.94414	GEYER	KXO-V97T 32.768 MHz
12.94404	GEYER	KXO-V97T 33.0 MHz
12.94102	GEYER	KXO-V97T 4.91520 MHz 100ppm 3.3V TTL/CMOS
12.94412	GEYER	KXO-V97T 40.0 MHz
12.94364	GEYER	KXO-V97T 48.0 MHz
12.94512	GEYER	KXO-V97T 50.0 MHz
12.94421	GEYER	KXO-V97T 50.0 MHz 3.3V +/-50ppm
12.94408	GEYER	KXO-V97T 66.0 MHz
12.94470	GEYER	KXO-V97T 8.0 MHz
12.94411	GEYER	KXO-V97T 80.0 MHz
12.94606	GEYER	KXO-V99 100.0 MHz 3.3V
12.94600	GEYER	KXO-V99 16.0 MHz 50ppm 3.3V
12.94678	GEYER	KXO-V99 16.384 MHz 3.3V
12.94672	GEYER	KXO-V99 2.048 MHz 3.3V
12.94720	GEYER	KXO-V99 2.0480 MHz 50ppm 1.8V
12.94628	GEYER	KXO-V99 24.0 MHz
12.94608	GEYER	KXO-V99 25.0 MHz
12.94601	GEYER	KXO-V99 32.0 MHz
12.94603	GEYER	KXO-V99 48.0 MHz
12.94604	GEYER	KXO-V99 50.0 MHz
12.94730	GEYER	KXO-V99 50.0 MHz 25ppm 3.3V
12.94605	GEYER	KXO-V99 80.0 MHz
12.94658	GEYER	KXO-V99T 100.0 MHz 2.5V
12.94617	GEYER	KXO-V99T 100.00 MHz
12.94616	GEYER	KXO-V99T 25.0 MHz 3.3V
12.94659	GEYER	KXO-V99T 40.0 MHz 2.5V
12.94751	GEYER	KXO-V99T 50.0 MHz 50ppm 3.3V
12.94753	GEYER	KXO-V99T 8.0 MHz 100ppm 3.3V
12.94660	GEYER	KXO-V99T 80.0 MHz 2.5V
12.98773	GEYER	KX-SF 433.92 MHz SAW Filter
12.98757	GEYER	KX-SF 868 MHz 3.8x3.8
12.98756	GEYER	KX-SF 868 MHz 3x3
12.98772	GEYER	KX-SF 869.0 MHz SAW Filter

12.99803	GEYER	KX-ZTBJ 1.0 MHz
12.99501	GEYER	KX-ZTT CC MG 4.0 MHz
12.99100	GEYER	KX-ZTT CR MG 4.0MHz
12.99503	GEYER	KX-ZTT CS MT 10.0 MHz
12.99507	GEYER	KX-ZTT CS MX 20.0 MHz
12.99203	GEYER	KX-ZTT CV 12.0 MHz
12.99612	GEYER	KX-ZTT MG 2.0 MHz
12.99600	GEYER	KX-ZTT MG 3.58 MHz
12.99601	GEYER	KX-ZTT MG 4.0 MHz
12.99607	GEYER	KX-ZTT MG 8.0 MHz
12.99609	GEYER	KX-ZTT MT 10.0 MHz